






DNH


CP-6 (T)

ISO 9001 CERTIFIED



◀ Cable entries

CIRCUIT
DIAGRAM



70/100 volt combined transformer		
Primary connections		
White : Green	70 V	
White : Red	100 V	
Secondary nominal tapings		
C : 1	6,0 W	
C : 2	3,0 W	
C : 3	1,5 W	
C : 4	0,5 W	

Sound pressure levels at 1W/1m Sine wave

SPL vs Freq



Specifications

Material / Color	ABS / RAL 9010
Mounting	3 Screws
Termination	Internal screw connections
Weight w/transformer	0,6 kg
IP-rating	
Max. / min. amb. temp	90°C / -20°C
Rated / max. power	6 W / 10 W
SPL 1W/1m	86 dB
SPL rated power	94 dB
Effective freq. range	170 – 18000 Hz
Dispersion (-6dB) 1kHz / 4kHz	180° / 110°
Directivity factor, Q(2kHz)	
Options	Impedance, colors, labels

Installation, Operation and Maintenance Procedures

- To open the loudspeaker, press the two clips on each side of the loudspeaker and separate the cabinet from the chassis.
- Enter the cable through a suitable cable entrance.
- Fasten the chassis to the wall or roof with 3 screws.
- Clip the cabinet on to the chassis after termination.
- For optimum performance, always use the correct voltage / power and operate within the frequency limits as stated.
- Do not open the loudspeaker when energized.
- This loudspeaker is supplied with a 2 year warranty against defective workmanship.

DNH reserves the right to alter specifications without notice

